



J1939 Procon_{TB} Configuration Examples:

Need Help? CAI Provides No-cost Technical Support for the Lifetime of the Product.

J1939 Protocol with RS232 output.	P/N: PC1939MBRS2 (MODBUS)
J1939 Protocol with RS485 output.	P/N: PC1939MBRS4 (MODBUS)
J1708 Protocol with RS232 output.	P/N: PC1708MBRS2 (MODBUS)
J1708 Protocol with RS485 output.	P/N: PC1708MBRS4 (MODBUS)

① J1939 - ⑦ +12/24V
② J1939 SHIELD ⑧ RS232 TX
③ J1939 + ⑨ RS232 RX
④ CHAS. GND ⑩ SIG. GND
⑤ J1708 + ⑪ RS485 -
⑥ J1708 - ⑫ RS485 +

① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ⑩ ⑪ ⑫

For other protocols please call (780) 963-8930 or Email: sales@c-a-i.net