



TMT78N2K Current Supported Parameters

Engine RPM	Percent engine load
Engine boost pressure	Rated engine speed
Engine oil pressure	Engine VIN
Engine oil temperature	Engine software ID
Engine oil level	Transmission direction (forward, neutral, reverse)
Engine coolant temperature	Transmission oil pressure
Engine coolant pressure	Transmission oil temperature
Engine fuel rate	Transmission oil level
Engine fuel pressure	Transmission discrete status
Engine fuel level	Alternator potential
Average fuel rate	Battery potential
Trip fuel used	Battery current
Engine discrete status	Active/Inactive diagnostic trouble codes*
Total engine hours	

* Diagnostic trouble codes are translated from J1587/J1708 into J1939 DM1 and DM2 messages, and are only readable by devices that specifically support them.